


AMBER

Assembly Instructions


CHERRYMAN

A829 Storage Bookcase 4 Shelf


Ⓐ Ø15×33 15(PCS)




Ⓑ Ø8×30 20(PCS)




Ⓒ Ø22×27 4(PCS)




Ⓓ Ø5×18 20(PCS)




Ⓔ Ø3.5×16 8(PCS)



Ⓕ Ø15×1 15(PCS)



Ⓖ 25×25×20 2(PCS)




AMBER

Assembly Instructions

CHERRYMAN

A829 Storage Bookcase 4 Shelf



AMBER

Assembly Instructions

CHERRYMAN

A829 Storage Bookcase 4 Shelf

